

How to Guide: Dixon Paint Stick 3m to 5m




Step 1.



Screw the paint holder into the paint stick.

Step 2.



Tie the string through the eyelet.

Step 3.



Lift and rotate the trigger pin to align the can holder rings, allowing insertion of the aerosol can.

Step 4.




Securely tighten the thumb screw to prevent the can from detaching.

Step 5.



Ensure the trigger pin rests on the button of the aerosol can. The can button will be activated when the string cord is pulled, and vice versa.

Step 6.



Press the red button to extend the handle to the desired length. Choose any hole slot to lock the position.

NOTE: When you have completed the task, press the red button to release the telescopic pole from the locked hole slot and compress it. The telescopic pole can extend up to 5m and compress to a length of 2.5m.